

OPEN ENDED LAB REPORT



Course Code : EEE 4416

Course Name : Simulation Lab

App Name : Analog Modulation Scheme

Members:

<u>NAME</u>	<u>ID</u>
Khandaker Adeba Tabassum	200021102
Sadat Al Rashad	200021106
Md. Nazmul Aman	200021132

Description:

In this project we made a MATLAB App named 'Analog Modulation Scheme' using gui which takes input for message and carrier waveform amplitude, frequency, modulation index and sampling frequency. It shows message waveform, carrier waveform and modulated waveform as output. It can modulate the message signal using AM, FM, PM techniques and PAM, PPM, PWM techniques when carrier is pulse.

MATLAB Code:

```
classdef ModOEL_exported < matlab.apps.AppBase

    % Properties that correspond to app components
    properties (Access = public)
        UIFigure                matlab.ui.Figure
        ANALOGMODULATIONSCHEMESLabel matlab.ui.control.Label
        Image                   matlab.ui.control.Image
        WarningsPanel           matlab.ui.container.Panel
        SawtoothAmplitudeErrorLabel matlab.ui.control.Label
        Lamp_3                  matlab.ui.control.Lamp
        LowCarrierFreqLabel     matlab.ui.control.Label
        OvermodulationLabel     matlab.ui.control.Label
        Lamp_2                  matlab.ui.control.Lamp
        Lamp                    matlab.ui.control.Lamp
        ModulationtypeKnob      matlab.ui.control.DiscreteKnob
        ModulationtypeKnobLabel matlab.ui.control.Label
        CarrierPanel            matlab.ui.container.Panel
        ModulateButton          matlab.ui.control.Button
        TextArea_6              matlab.ui.control.TextArea
        TextArea_3              matlab.ui.control.TextArea
        AmplitudeSlider_carrier matlab.ui.control.Slider
        AmplitudeSlider_2Label  matlab.ui.control.Label
        CarrierFrequencyKnob    matlab.ui.control.Knob
        CarrierFrequencyKnobLabel matlab.ui.control.Label
        CarrierWaveformDropDown matlab.ui.control.DropDown
        CarrierWaveformDropDownLabel matlab.ui.control.Label
        MessagePanel            matlab.ui.container.Panel
        TextArea_5              matlab.ui.control.TextArea
        TextArea_4              matlab.ui.control.TextArea
        TextArea_2              matlab.ui.control.TextArea
        TextArea                matlab.ui.control.TextArea
        ModulationIndexSlider   matlab.ui.control.Slider
        ModulationIndexSliderLabel matlab.ui.control.Label
        MessagewaveformDropDown matlab.ui.control.DropDown
        MessagewaveformDropDownLabel matlab.ui.control.Label
        SamplingFrequencyKnob   matlab.ui.control.Knob
        SamplingFrequencyKnobLabel matlab.ui.control.Label
        MessageFrequencyKnob    matlab.ui.control.Knob
        MessageFrequencyKnobLabel matlab.ui.control.Label
        AmplitudeSlider_msg     matlab.ui.control.Slider
        AmplitudeSliderLabel    matlab.ui.control.Label
        UIAxes_mod              matlab.ui.control.UIAxes
        UIAxes_carrier          matlab.ui.control.UIAxes
        UIAxes_msg              matlab.ui.control.UIAxes
    end

    properties (Access = private)
        Am % Description
        fm
        fs
        fc
        Ac
        k
    end

    % Callbacks that handle component events
```

```

methods (Access = private)

% Value changed function: CarrierWaveformDropDown
function CarrierWaveformDropDownValueChanged(app, event)
    if strcmp(app.CarrierWaveformDropDown.Value, 'Pulse')
        app.ModulationtypeKnob.Items = {'PAM', 'PPM', 'PWM'};
    else
        app.ModulationtypeKnob.Items = {'AM', 'FM', 'PM'};
    end
end

% Value changed function: AmplitudeSlider_msg
function AmplitudeSlider_msgValueChanged(app, event)
    app.Am = app.AmplitudeSlider_msg.Value;
end

% Value changed function: MessageFrequencyKnob
function MessageFrequencyKnobValueChanged(app, event)
    app.fm = app.MessageFrequencyKnob.Value;
    app.TextArea.Value=num2str(app.fm);
end

% Value changed function: SamplingFrequencyKnob
function SamplingFrequencyKnobValueChanged(app, event)
    app.fs = app.SamplingFrequencyKnob.Value;
    app.TextArea_2.Value=num2str(app.fs);
end

% Value changed function: AmplitudeSlider_carrier
function AmplitudeSlider_carrierValueChanged(app, event)
    app.Ac = app.AmplitudeSlider_carrier.Value;
end

% Value changed function: CarrierFrequencyKnob
function CarrierFrequencyKnobValueChanged(app, event)
    app.fc = app.CarrierFrequencyKnob.Value;
    app.TextArea_3.Value=num2str(app.fc);
end

% Value changed function: ModulationIndexSlider
function ModulationIndexSliderValueChanged(app, event)
    app.k = app.ModulationIndexSlider.Value;
end

% Button pushed function: ModulateButton
function ModulateButtonPushed(app, event)
    t=0:1/app.fs:1;
    str=app.MessagewaveformDropDown.Value;
    switch str
        case {'Sinusoidal'}
            m= app.Am*sin(2*pi*app.fm*t);
        case {'Square'}
            m= app.Am*square(2*pi*app.fm*t,50);
        case {'Triangular'}
            m= app.Am*sawtooth(2*pi*app.fm*t,0.50);
    end
    plot(app.UIAxes_msg,t,m,'r');
    str2=app.CarrierWaveformDropDown.Value;
    switch str2
        case {'Sinusoidal'}
            c= app.Ac*sin(2*pi*app.fc*t);
        case {'Square'}
            c= app.Ac*square(2*pi*app.fc*t,50);
        case {'Pulse'}
            c=square(2*pi*app.fc*t,50);
            c(c<0)=0;
    end
    plot(app.UIAxes_carrier,t,c,'g');
    str3=app.ModulationtypeKnob.Value;
    switch str3
        case {'AM'}
            x = (1 + app.k * m) .* c;
            if app.k*(app.Am)>1
                app.Lamp.Color='r';
            else
                app.Lamp.Color='g';
            end
        case {'FM'}
            m_int = (1/app.fs)*cumsum(m);

```

```

        x = app.Ac*cos(2*pi*app.fc*t + 2*pi*app.k*m_int);
    case {'PM'}
        x=app.Ac*cos(2*pi*app.fc*t+ app.k*m);
    case {'PAM'}
        x=m.*c;
    case {'PWM'}
        s=app.Ac*sawtooth(2*pi*10*app.fm*t+pi);
        n=length(s);
        x=zeros(1,n);
        for i=1:n
            if (m(i)>=s(i))
                x(i)=1;
            end
        end
        if app.Ac<app.Am
            app.Lamp_3.Color='r';
        else
            app.Lamp_3.Color='g';
        end
    case {'PPM'}
        s=app.Ac*sawtooth(2*pi*10*app.fm*t+pi);
        n=length(s);
        pwm=zeros(1,n);
        for i=1:n
            if (m(i)>=s(i))
                pwm(i)=1;
            end
        end
        b=diff(pwm);
        x=zeros(size(pwm));
        z=find(b==-1);
        a=z(1:end-1);
        b=z(2:end);
        p=floor(0.5*min(b-a));
        for i=1:size(z,2)
            x(z(i):(z(i)+p))=ones(1,p+1);
        end
        x=x(1:size(t,2));
        if app.Ac<app.Am
            app.Lamp_3.Color='r';
        else
            app.Lamp_3.Color='g';
        end
    end
    plot(app.UIAxes_mod,t,x,'b');
    if app.fc<app.fm
        app.Lamp_2.Color='r';
    else
        app.Lamp_2.Color='g';
    end
end

% Value changed function: ModulationtypeKnob
function ModulationtypeKnobValueChanged(app, event)
    value = app.ModulationtypeKnob.Value;
    if strcmp(value, {'FM'})
        app.ModulationIndexSlider.Limits=[0 500];
        app.CarrierFrequencyKnob.Limits=[0 500];
    elseif strcmp(value, {'PM'})
        app.ModulationIndexSlider.Limits=[0 500];
        app.CarrierFrequencyKnob.Limits=[0 500];
    else
        app.ModulationIndexSlider.Limits=[0 2];
        app.CarrierFrequencyKnob.Limits=[0 50];
    end
end

% Value changing function: ModulationIndexSlider
function ModulationIndexSliderValueChanging(app, event)
    app.k = event.Value;
    app.TextArea_4.Value=num2str(app.k);
end

% Value changing function: AmplitudeSlider_msg
function AmplitudeSlider_msgValueChanging(app, event)
    app.Am = event.Value;
    app.TextArea_5.Value=num2str(app.Am);
end

% Value changing function: AmplitudeSlider_carrier
function AmplitudeSlider_carrierValueChanging(app, event)

```

```

        app.Ac = event.Value;
        app.TextArea_6.Value=num2str(app.Ac);
    end

    % Value changing function: MessageFrequencyKnob
    function MessageFrequencyKnobValueChanging(app, event)
        app.fm = event.Value;
        app.TextArea.Value=num2str(app.fm);
    end

    % Value changing function: SamplingFrequencyKnob
    function SamplingFrequencyKnobValueChanging(app, event)
        app.fs= event.Value;
        app.TextArea_2.Value=num2str(app.fs);
    end

    % Value changing function: CarrierFrequencyKnob
    function CarrierFrequencyKnobValueChanging(app, event)
        app.fc = event.Value;
        app.TextArea_3.Value=num2str(app.fc);
    end
end

% Component initialization
methods (Access = private)

    % Create UIFigure and components
    function createComponents(app)

        % Create UIFigure and hide until all components are created
        app.UIFigure = uifigure('Visible', 'off');
        app.UIFigure.Color = [0.8392 0.8471 0.9569];
        app.UIFigure.Position = [100 100 939 848];
        app.UIFigure.Name = 'MATLAB App';

        % Create UIAxes_msg
        app.UIAxes_msg = uiaxes(app.UIFigure);
        title(app.UIAxes_msg, {'Message waveform'; ''})
        xlabel(app.UIAxes_msg, 'X')
        ylabel(app.UIAxes_msg, 'Y')
        app.UIAxes_msg.FontName = 'Comic Sans MS';
        app.UIAxes_msg.FontWeight = 'bold';
        app.UIAxes_msg.XGrid = 'on';
        app.UIAxes_msg.YGrid = 'on';
        app.UIAxes_msg.FontSize = 12;
        app.UIAxes_msg.Position = [323 377 298 183];

        % Create UIAxes_carrier
        app.UIAxes_carrier = uiaxes(app.UIFigure);
        title(app.UIAxes_carrier, {'Carrier waveform'; ''})
        xlabel(app.UIAxes_carrier, 'X')
        ylabel(app.UIAxes_carrier, 'Y')
        app.UIAxes_carrier.FontName = 'Comic Sans MS';
        app.UIAxes_carrier.FontWeight = 'bold';
        app.UIAxes_carrier.XGrid = 'on';
        app.UIAxes_carrier.YGrid = 'on';
        app.UIAxes_carrier.Position = [323 195 298 183];

        % Create UIAxes_mod
        app.UIAxes_mod = uiaxes(app.UIFigure);
        title(app.UIAxes_mod, {'Modulated signal waveform'; ''})
        xlabel(app.UIAxes_mod, 'X')
        ylabel(app.UIAxes_mod, 'Y')
        app.UIAxes_mod.FontName = 'Comic Sans MS';
        app.UIAxes_mod.FontWeight = 'bold';
        app.UIAxes_mod.XGrid = 'on';
        app.UIAxes_mod.YGrid = 'on';
        app.UIAxes_mod.Position = [323 13 298 183];

        % Create MessagePanel
        app.MessagePanel = uipanel(app.UIFigure);
        app.MessagePanel.TitlePosition = 'centertop';
        app.MessagePanel.Title = 'Message';
        app.MessagePanel.BackgroundColor = [0.9216 0.9294 1];
        app.MessagePanel.Position = [27 243 287 548];

        % Create AmplitudeSliderLabel
        app.AmplitudeSliderLabel = uilabel(app.MessagePanel);
        app.AmplitudeSliderLabel.HorizontalAlignment = 'right';
        app.AmplitudeSliderLabel.Position = [23 443 59 22];
        app.AmplitudeSliderLabel.Text = {'Amplitude'; ''};

        % Create AmplitudeSlider_msg

```

```

app.AmplitudeSlider_msg = uislider(app.MessagePanel);
app.AmplitudeSlider_msg.Limits = [0 5];
app.AmplitudeSlider_msg.ValueChangedFcn = createCallbackFcn(app, @AmplitudeSlider_msgValueChanged,
true);
app.AmplitudeSlider_msg.ValueChangingFcn = createCallbackFcn(app,
@AmplitudeSlider_msgValueChanging, true);
app.AmplitudeSlider_msg.Position = [103 452 161 3];

% Create MessageFrequencyKnobLabel
app.MessageFrequencyKnobLabel = uilabel(app.MessagePanel);
app.MessageFrequencyKnobLabel.HorizontalAlignment = 'center';
app.MessageFrequencyKnobLabel.Position = [24 240 114 22];
app.MessageFrequencyKnobLabel.Text = {'Message Frequency'; ''};

% Create MessageFrequencyKnob
app.MessageFrequencyKnob = uiknob(app.MessagePanel, 'continuous');
app.MessageFrequencyKnob.Limits = [0 5];
app.MessageFrequencyKnob.ValueChangedFcn = createCallbackFcn(app,
@MessageFrequencyKnobValueChanged, true);
app.MessageFrequencyKnob.ValueChangingFcn = createCallbackFcn(app,
@MessageFrequencyKnobValueChanging, true);
app.MessageFrequencyKnob.Position = [58 283 44 44];

% Create SamplingFrequencyKnobLabel
app.SamplingFrequencyKnobLabel = uilabel(app.MessagePanel);
app.SamplingFrequencyKnobLabel.HorizontalAlignment = 'center';
app.SamplingFrequencyKnobLabel.Position = [158 240 115 22];
app.SamplingFrequencyKnobLabel.Text = {'Sampling Frequency'; ''};

% Create SamplingFrequencyKnob
app.SamplingFrequencyKnob = uiknob(app.MessagePanel, 'continuous');
app.SamplingFrequencyKnob.Limits = [0 10000];
app.SamplingFrequencyKnob.ValueChangedFcn = createCallbackFcn(app,
@SamplingFrequencyKnobValueChanged, true);
app.SamplingFrequencyKnob.ValueChangingFcn = createCallbackFcn(app,
@SamplingFrequencyKnobValueChanging, true);
app.SamplingFrequencyKnob.Position = [192 283 44 44];

% Create MessagewaveformDropDownLabel
app.MessagewaveformDropDownLabel = uilabel(app.MessagePanel);
app.MessagewaveformDropDownLabel.HorizontalAlignment = 'right';
app.MessagewaveformDropDownLabel.Position = [21 488 110 22];
app.MessagewaveformDropDownLabel.Text = {'Message waveform'; ''};

% Create MessagewaveformDropDown
app.MessagewaveformDropDown = uidropdown(app.MessagePanel);
app.MessagewaveformDropDown.Items = {'Sinusoidal', 'Square', 'Triangular', ''};
app.MessagewaveformDropDown.Position = [146 488 123 22];
app.MessagewaveformDropDown.Value = 'Sinusoidal';

% Create ModulationIndexSliderLabel
app.ModulationIndexSliderLabel = uilabel(app.MessagePanel);
app.ModulationIndexSliderLabel.HorizontalAlignment = 'right';
app.ModulationIndexSliderLabel.Position = [17 108 97 27];
app.ModulationIndexSliderLabel.Text = {'Modulation Index'; ''};

% Create ModulationIndexSlider
app.ModulationIndexSlider = uislider(app.MessagePanel);
app.ModulationIndexSlider.Limits = [0 2];
app.ModulationIndexSlider.ValueChangedFcn = createCallbackFcn(app,
@ModulationIndexSliderValueChanged, true);
app.ModulationIndexSlider.ValueChangingFcn = createCallbackFcn(app,
@ModulationIndexSliderValueChanging, true);
app.ModulationIndexSlider.Position = [142 122 120 3];

% Create TextArea
app.TextArea = uitextarea(app.MessagePanel);
app.TextArea.Position = [26 183 108 23];

% Create TextArea_2
app.TextArea_2 = uitextarea(app.MessagePanel);
app.TextArea_2.Position = [159 183 108 23];

% Create TextArea_4
app.TextArea_4 = uitextarea(app.MessagePanel);
app.TextArea_4.Position = [91 32 108 23];

% Create TextArea_5
app.TextArea_5 = uitextarea(app.MessagePanel);
app.TextArea_5.Position = [90 372 108 23];

% Create CarrierPanel
app.CarrierPanel = uipanel(app.UIFigure);

```

```

app.CarrierPanel.BorderType = 'none';
app.CarrierPanel.TitlePosition = 'centertop';
app.CarrierPanel.Title = 'Carrier';
app.CarrierPanel.BackgroundColor = [0.9216 0.9294 1];
app.CarrierPanel.Position = [637 243 284 548];

% Create CarrierWaveformDropDownLabel
app.CarrierWaveformDropDownLabel = uilabel(app.CarrierPanel);
app.CarrierWaveformDropDownLabel.HorizontalAlignment = 'right';
app.CarrierWaveformDropDownLabel.Position = [12 490 103 22];
app.CarrierWaveformDropDownLabel.Text = 'Carrier Waveform';

% Create CarrierWaveformDropDown
app.CarrierWaveformDropDown = uidropdown(app.CarrierPanel);
app.CarrierWaveformDropDown.Items = {'Sinusoidal', 'Square', 'Pulse'};
app.CarrierWaveformDropDown.ValueChangedFcn = createCallbackFcn(app,
@CarrierWaveformDropDownValueChanged, true);
app.CarrierWaveformDropDown.Position = [137 490 130 22];
app.CarrierWaveformDropDown.Value = 'Sinusoidal';

% Create CarrierFrequencyKnobLabel
app.CarrierFrequencyKnobLabel = uilabel(app.CarrierPanel);
app.CarrierFrequencyKnobLabel.HorizontalAlignment = 'center';
app.CarrierFrequencyKnobLabel.Position = [97 223 103 27];
app.CarrierFrequencyKnobLabel.Text = {'Carrier Frequency'; ''; ''};

% Create CarrierFrequencyKnob
app.CarrierFrequencyKnob = uiknob(app.CarrierPanel, 'continuous');
app.CarrierFrequencyKnob.Limits = [0 50];
app.CarrierFrequencyKnob.ValueChangedFcn = createCallbackFcn(app,
@CarrierFrequencyKnobValueChanged, true);
app.CarrierFrequencyKnob.ValueChangingFcn = createCallbackFcn(app,
@CarrierFrequencyKnobValueChanging, true);
app.CarrierFrequencyKnob.Position = [126 284 44 44];

% Create AmplitudeSlider_2Label
app.AmplitudeSlider_2Label = uilabel(app.CarrierPanel);
app.AmplitudeSlider_2Label.HorizontalAlignment = 'right';
app.AmplitudeSlider_2Label.Position = [22 439 59 22];
app.AmplitudeSlider_2Label.Text = {'Amplitude'; ''};

% Create AmplitudeSlider_carrier
app.AmplitudeSlider_carrier = uislider(app.CarrierPanel);
app.AmplitudeSlider_carrier.Limits = [0 5];
app.AmplitudeSlider_carrier.ValueChangedFcn = createCallbackFcn(app,
@AmplitudeSlider_carrierValueChanged, true);
app.AmplitudeSlider_carrier.ValueChangingFcn = createCallbackFcn(app,
@AmplitudeSlider_carrierValueChanging, true);
app.AmplitudeSlider_carrier.Position = [101 457 161 3];

% Create TextArea_3
app.TextArea_3 = uitextarea(app.CarrierPanel);
app.TextArea_3.Position = [92 184 108 23];

% Create TextArea_6
app.TextArea_6 = uitextarea(app.CarrierPanel);
app.TextArea_6.Position = [91 373 108 23];

% Create ModulateButton
app.ModulateButton = uibutton(app.CarrierPanel, 'push');
app.ModulateButton.ButtonPushedFcn = createCallbackFcn(app, @ModulateButtonPushed, true);
app.ModulateButton.Position = [68 33 164 39];
app.ModulateButton.Text = 'Modulate!';

% Create ModulationtypeKnobLabel
app.ModulationtypeKnobLabel = uilabel(app.UIFigure);
app.ModulationtypeKnobLabel.HorizontalAlignment = 'center';
app.ModulationtypeKnobLabel.Position = [131 43 90 22];
app.ModulationtypeKnobLabel.Text = {'Modulation type'; ''};

% Create ModulationtypeKnob
app.ModulationtypeKnob = uiknob(app.UIFigure, 'discrete');
app.ModulationtypeKnob.Items = {'AM', 'FM', 'PM'};
app.ModulationtypeKnob.ValueChangedFcn = createCallbackFcn(app, @ModulationtypeKnobValueChanged,
true);
app.ModulationtypeKnob.Position = [126 80 100 100];
app.ModulationtypeKnob.Value = 'AM';

% Create WarningsPanel
app.WarningsPanel = uipanel(app.UIFigure);
app.WarningsPanel.TitlePosition = 'centertop';
app.WarningsPanel.Title = 'Warnings';
app.WarningsPanel.BackgroundColor = [0.9216 0.9294 1];

```

```

app.WarningsPanel.Position = [638 48 284 165];

% Create Lamp
app.Lamp = uilamp(app.WarningsPanel);
app.Lamp.Position = [36 112 20 20];

% Create Lamp_2
app.Lamp_2 = uilamp(app.WarningsPanel);
app.Lamp_2.Position = [37 69 20 20];

% Create OvermodulationLabel
app.OvermodulationLabel = uilabel(app.WarningsPanel);
app.OvermodulationLabel.Position = [100 110 139 22];
app.OvermodulationLabel.Text = 'Overmodulation';

% Create LowCarrierFreqLabel
app.LowCarrierFreqLabel = uilabel(app.WarningsPanel);
app.LowCarrierFreqLabel.Position = [100 71 139 22];
app.LowCarrierFreqLabel.Text = 'Low Carrier Freq.';

% Create Lamp_3
app.Lamp_3 = uilamp(app.WarningsPanel);
app.Lamp_3.Position = [38 32 20 20];

% Create SawtoothAmplitudeErrorLabel
app.SawtoothAmplitudeErrorLabel = uilabel(app.WarningsPanel);
app.SawtoothAmplitudeErrorLabel.Position = [101 31 142 22];
app.SawtoothAmplitudeErrorLabel.Text = 'Sawtooth Amplitude Error';

% Create Image
app.Image = uiimage(app.UIFigure);
app.Image.Position = [379 570 232 236];
app.Image.ImageSource = 'PikPng.com_anime-transparent-png_1850423.png';

% Create ANALOGMODULATIONSCHEMESLabel
app.ANALOGMODULATIONSCHEMESLabel = uilabel(app.UIFigure);
app.ANALOGMODULATIONSCHEMESLabel.HorizontalAlignment = 'center';
app.ANALOGMODULATIONSCHEMESLabel.FontName = 'Comic Sans MS';
app.ANALOGMODULATIONSCHEMESLabel.FontSize = 15;
app.ANALOGMODULATIONSCHEMESLabel.FontWeight = 'bold';
app.ANALOGMODULATIONSCHEMESLabel.Position = [369 669 186 96];
app.ANALOGMODULATIONSCHEMESLabel.Text = {'ANALOG'; 'MODULATION '; 'SCHEMES'; ''};

% Show the figure after all components are created
app.UIFigure.Visible = 'on';
end
end

% App creation and deletion
methods (Access = public)

% Construct app
function app = ModOEL_exported

% Create UIFigure and components
createComponents(app)

% Register the app with App Designer
registerApp(app, app.UIFigure)

if nargin == 0
clear app
end
end



% Code that executes before app deletion
function delete(app)

% Delete UIFigure when app is deleted
delete(app.UIFigure)
end
end
end



```


Output:



AM:




FM:




PM:




PAM:



PPM:




PWM:



Opening the GUI:

As we have designed this UI in Appdesigner, .fig file could not be created which is for Guide. We have provided the .mlappinstall file as a replacement of .fig file. To open it at first install the app from “App” tab in MATLAB:




Then choose the file and install it. Then open it from the app list.


Additional features:

This app shows 3 warnings:

1. Over modulation warning when modulation index is greater than 1 in AM.
2. Low carrier frequency warning when $f_m > f_c$
3. Sawtooth amplitude error when $A_m > A_c$ in PWM and PPM.

Outputs for errors are given below:





Limitations:

Sometimes it shows carrier waveform instead of showing modulated signal waveform. This is because of technical error so we couldn't fix it. But in that case if 'modulate' button is pressed again, it shows the correct output.

In case of showing warnings/error, if the bulb is on, then it must be turned off by giving proper input before going to other modulation techniques. Otherwise the bulb remains on.

We are planning to work on its limitations and add some other features to improve its performance in future.